



ADDENDUM



WARRANTY

For any Preverco PreOil™ oiled product, the warranty that applies is the same as for any comparable Preverco product. It covers structural and manufacturing defects and is limited to the original buyer.

However, no warranty applies to the durability of the oil. This, by its very nature, cannot be guaranteed as it depends on the maintenance provided by the owner to the floor. If maintenance is done according to the Preverco requirements, you will enjoy your PreOil™ oiled floor for years to come. Preverco offers a range of products for maintenance, repair and revitalization of your PreOil™ oiled floors. Preverco is committed to make available the necessary products for the maintenance and repair of your PreOil™ oiled hardwood floor.

FOR ANY INFORMATION ABOUT:

- The responsibility of the manufacturer;
- Exclusions of warranty;
- The responsibility of the customer;
- Items to be monitored before and after the installation of your PreOil™ oiled floor;

Please refer to the standard Preverco warranty depending on the chosen platforms (SolidClassic or Engineered)

MAINTENANCE

Using the Preverco hardwood floors cleaner is essential. It should be used to preserve the finish of your floor especially in high traffic areas. This product can be used for PreOil™ oiled floors as well as regular pre-finished floors.

Preverco cleaner is a product that restores the luster to your floors and cleaning it. It should be applied as needed and according to the instructions on the bottle. This product is available as a spray or recharge.

Use the recommended quantity on the label no more. Especially do not use commercial detergents; that might alter the finish of your floor.

As with any hardwood floor for regular maintenance, we recommend cleaning your floor only with a slightly damp microfibre mop.

Never clean the floor with water.

In addition, some precautions will help to preserve the beauty of your floor:

- Regularly sweep or vacuum the floor to remove all dry dirt;
- If liquid is spilled on the floor, wipe immediately with a dry cloth;
- Use felt pads under all furniture legs.

REVITALIZATION

When simple cleaning is not enough anymore to restore the original appearance of your PreOil™ oiled floor or after a major damage (such as a deep scratch) revitalization or repair may become necessary.

Preverco offers a whole range of maintenance products, to repair and revitalize your PreOil™ oiled floor. The procedure varies slightly depending on the work to be done.

NOTE: FIRENZE and BARCELONA colors consist of a 2 stains mix, applied in factory. Contact our technical staff if you want to make a complete revitalization of these colors. (1-800-667-2725)

OIL RECOATING BY HAND (SMALL SURFACE):

STEP 1: Thoroughly clean the floor before starting work using the specially designed Preverco products. Leave to dry and then begin application. (#PE-2000-000-00)

STEP 2: Spread a small quantity of PreOil™ clear oil (#GC-HUIL-000-000) directly on the floor surface of approximately +/-5ft x 5ft.

STEP 3: Use a clean and dry cotton cloth or sponge.

STEP 4: Ensure uniform application so as to obtain a fine film of oil on the surface. Leave to penetrate and wipe off any excess with a cloth in order to leave only a very thin coat.

STEP 5: Let dry for 30 minutes between each coat and repeat if necessary.

STEP 6: Proceed section by section over the entire floor surface, making sure that all areas being covered are uniform.

STEP 7: Pay particular attention to corners and edges along the walls.

STEP 8: Allow to dry completely for 16-24 hours before circulating freely and reinstall furniture.

STEP 9: To ensure safety, dispose of all oil-soaked cloths in a bucket of water. Otherwise, soiled linen may ignite spontaneously.

OIL RECOATING USING A ROTARY BUFFER: (LARGE SURFACE):

- STEP 1:** Thoroughly clean the floor before starting work using the specially designed Preverco products. Leave to dry and then begin application. (#PE-2000-000-00)
- STEP 2:** Use an industrial floor buffer (available on rental).
- STEP 3:** Use a white buffer pad.
- STEP 4:** Pour the PreOil™ clear oil (#GC-HUIL-000-000) in a bottle with spout to facilitate the work.
- STEP 5:** Apply directly onto the wood floor in small quantities (size of an egg).
- STEP 6:** Position the centre of the buffer pad on the oil.
- STEP 7:** Divide and work the room in sections of approximately 50 sq.ft..
- STEP 8:** Apply the oil manually in corners and around edges of the room.
- STEP 9:** Apply a second coat if needed, waiting 30 minutes between coats.
- STEP 10:** Leave to dry completely for 16-24 hours before circulating freely and reinstall furniture.
- STEP 11:** To ensure safety, dispose of all oil-soaked cloths in a bucket of water.

REPAIRING SCRATCHES AND STAINS

Repair is necessary when imperfections such as large scrapes, scratches or stains become visible on the floor.

REPAIRING SUPERFICIAL SCRATCHES (STAINED OIL):

- STEP 1:** Thoroughly clean the surface to be repaired before starting work using the specially designed recommended products. Leave to dry and then begin application. (#PE-2000-000-00)
- STEP 2:** Apply the stained oil (choose the colour matching your floor among PreOil™ oiled finishing products) into the cavity using an applicator crayon (or a fine brush).
- STEP 3:** Let dry for approximately 1 minute.
- STEP 4:** Wipe the repaired area gently using a perpendicular motion so as to maintain all the imperfection's stain colouring.
- STEP 5:** Adjust and redo again if needed.
- STEP 6:** Leave to dry completely for approximately 24 hours.
- STEP 7:** Apply a coat of PreOil™ clear oil using a sponge or other type of manual applicator.

- STEP 8:** Wait for 1 minute.
- STEP 9:** Wipe progressively around the repair so as to assure uniformity of the repair coat.
- STEP 10:** Wait for 30 minutes and apply a second very thin coat of oil, over a larger surface around the repair.
- STEP 11:** Buffing with a white Scotch-Brite-type pad may be necessary 30 minutes after the last application to equalize the floor's lustre.
- STEP 12:** To ensure safety, dispose all of oil-soaked cloths in a bucket of water.

REPAIRING DEEP SCRATCHES (STAINED OIL):

- STEP 1:** Thoroughly clean the surface to be repaired before starting work using the specially designed products. Leave to dry and then begin application. (#PE-2000-000-00)
- STEP 2:** Using 120-150 grit sandpaper, sand the perimeter of the area to be repaired lightly, making sure to minimize damage to the stain colour.
- STEP 3:** Apply the stained oil (choose the colour matching your floor among PreOil™ oiled finishing products) into the cavity using an applicator crayon (or a fine brush).
- STEP 4:** Let dry for approximately 1 minute.
- STEP 5:** Wipe the repaired area gently using a perpendicular motion so as to maintain all the colour on the imperfection.
- STEP 6:** Adjust and redo again if needed.
- STEP 7:** Leave to dry completely for approximately 24 hours.
- STEP 8:** Apply a coat of clear oil using a sponge or other type of manual applicator
- STEP 9:** Wait for 1 minute.
- STEP 10:** Wipe progressively around the repair so as to assure uniformity of the repair coat.
- STEP 11:** Wait for 30 minutes and apply a second very thin coat of oil over a larger surface around the repair.
- STEP 12:** Buffing with a white Scotch-Brite-type pad may be necessary 30 minutes after the last application to equalize the floor's lustre.
- STEP 13:** To ensure safety, dispose of all oil-soaked cloths in a bucket of water